



HEEL AND LEAD BLOCK ADJUSTER FITTINGS
(For use with E-566 Cargo Blocks)




No. 572

Self-adjuster Fitting with Tension Pin, Cup Spring and Washers.




No. 573

Self-adjuster Fitting with Tension Pin, Coil Spring, Cup and Washers.




No. 574

Self-adjuster Fitting with Tension Pin, Cup Spring and Washers, and King Pin to fit Pad Eye (can also be furnished with 2 Tension Pins).




No. 576

Self-adjuster Fitting with Pad Jaw, King Pin, Tension Pin, Cup Spring and Washers.



No. 575

Self-adjuster Fitting with Tension Pin, Cup Spring, and Washer.



No. 571

Tension Pin with Cup Spring, Nut and Washers.



No. 570

Tension Pin with Coil Spring, Nut and Washers, Cotter and Cup.

When ordering Specify: "A" - Pin Diameter, "B" - Height of Fitting, and Tension Pin Diameter.