


## Warning and Application Instructions for Crosby S-4338 Pin Latch




### Important Safety Information Read and Follow

- Always inspect hook and pin latch before using.
- Never use a pin latch that is distorted or bent.
- Always make sure internal spring will force the pin latch forward closing throat opening of grab hook. (See Figure 1).
- When a Pin Latch is provided, it is designed to retain loose chain under slack condition.
- Always make sure hook supports the load. The pin latch must never support the load. (See Figure 1, 2, 3 and 4).
- Pin latch is not intended to be an anti-fouling device.
- Recommended for use with Crosby L-1338 or L-1358 Grab Hooks.


### Important – Instructions for Assembling




**Step 1:** Using a hammer and the correct roll-pin punch per chart on the right, drive the old latch pin assembly out of hook.



Hook Size		Punch Dia.	A
(in.)	(mm)	(in.)	(in.)
1/4	7	7/32	3
5/16	8	7/32	3
3/8	10	7/32	3
1/2	13	5/16	4
5/8	16	3/8	4



**Step 2:** Insert new S-4338 pin assembly into hook.



**Step 3:** Using hammer, tap lightly on latch pin head until guide bushing shoulder touches hook.

### ⚠ WARNING

- Loads may disengage from hook if proper procedures are not followed.
- A falling load may cause serious injury or death.
- Hook must always support the load. The load must never be supported by the pin latch.
- See OSHA Rule 1926.1431(g)(1)(i)(A) and 1926.1501(g)(4)(iv)(B). A hook and this style latch must not be used for lifting personnel.
- Read and understand these instructions before using hook and pin latch.




Figure 1




Figure 2




Figure 3




Figure 4